

Product Document



User Guide

UG000455

AS5116 Adapter Board

Adapter Board User Manual

AS5116-SO_EK_AB

v1-00 • 2019-Oct-22

Content Guide

1	Introduction.....	3	5	Hardware.....	9
1.1	Kit Content.....	3	5.1	Schematics.....	9
1.2	Ordering Information	3	5.2	Layout	10
2	Board Description.....	4	6	Revision Information.....	11
2.1	Mounting the AS5116 Adapter Board	5	7	Legal Information	12
3	Adapter Board and Pinout	6			
4	Operation Case	7			
4.1	Programming with ams I&P Box (https://ams.com/usbi-pbox).....	8			

1 Introduction

The AS5116 Adapter Board is a small PCB allowing simple and quick testing or evaluation of the AS5116 magnetic position sensor without the need to build a test fixture or design an own PCB.

AS5116-SO_EK_AB is assembled with an AS5116 sensor.

1.1 Kit Content

Figure 1:
Adapter Board




Figure 2:
Diametric Magnet



Pos.	Item	Comment
1	AS5116-SO_EK_AB	Adapter board
2	AS5000-MD8H-2	Diametric magnet, D8x2.5 mm, NdFeB, Bomatec AG

1.2 Ordering Information

Ordering Code	Description
AS5116-SO_EK_AB	Adapter board assembled with AS5116 per default


2 Board Description

The PCB can be connected either to an external microcontroller or to the USB I&P Box, which is available on our webpage (USB I&P Box).

The connector, 2x5 pin header (not populated), is included to this kit and is required for power supply as well as UART and analog interface.


C1 (100 nF) and C2 (1 μ F) are capacitors to stabilize supply voltage.

Figure 3:
AS5116 Adapter Board



2.1 Mounting the AS5116 Adapter Board

Figure 4:
Mounting and Dimensions



A diametric magnetized magnet must be placed over or under the AS5116 sensor, and should be centered on the middle of the package with a tolerance of 0.5 mm. The air gap between the magnet surface and the package should be maintained in the range 0.5 mm to 3 mm. The magnet holder must not be ferromagnetic. Materials like brass, copper, aluminum, stainless steel are the best choices to make this part.

3 Adapter Board and Pinout

Figure 5:
Adapter Board Pinout




Figure 6:
Sensor Pinout




Figure 7:
Pinout Description

Pin# Board	Pin# AS5116	Symbol Board	Type	Description
P1 - 1	1	SINP	Analog output	Buffered sine channel, positive output
P1 - 2	8	COSP	Analog output	Buffered cosine channel, positive output
P1 - 3	3	VSS	Power supply	Ground
P1 - 4	5	VDD3	Power supply	3.3 V LDO output
P1 - 5	4	VDD5	Power supply	Positive supply voltage 5V
P1 - 6	3	VSS	Power supply	Ground
P1 - 7	6	UART	Digital I/O	Communication Pin for OTP programming
P1 - 8	3	VSS	Power supply	Ground
P1 - 9	7	COSN	Analog output	Buffered cosine channel, inverted output
P1 - 10	2	SINN	Analog output	Buffered sine channel, inverted output

4 Operation Case

The adapter board can be supplied with 5 V or with 3.3 V. In case of 5 V supply, the pin VDD3 is left open and VDD5 is connected to 5 V-supply voltage. In case of 3.3 V supply, the pin VDD3 and VDD5 are connected to 3.3 V-Supply voltage.

Digital I/O pins operates at 3.3 V level.

Figure 8:
3.3 V Operation





Figure 9:
5 V Operation



4.1 Programming with **ams I&P Box** (<https://ams.com/usbi-pbox>)

The Adapter Board cannot be connected directly to the I&P Box. There is a need of additional buffer, switched in between or use the Socket board (AS5116-SO_EK_SB). The Buffer-IC circuitry is on the Socket Board included

Additional recommended components are:

- Buffer-IC: 74HC1G125
- Resistor: 10 k Ohm.

Figure 10:
Programming via I&P Box






Figure 11:
Programming via I&P Box with Socket Board between



5 Hardware

5.1 Schematics

Figure 12:
Schematic




5.2 Layout

The adapter board is based on two copper layers. All signal and supply lines are placed on Top-Layer, Bottom-Layer is used as ground plane.

The four mounting holes are connected to GND as well.

Figure 13 :
PCB Layout



6 Revision Information

Changes from previous version to current revision v1-00	Page
---	------

Initial version

- Page and figure numbers for the previous version may differ from page and figure numbers in the current revision.
- Correction of typographical errors is not explicitly mentioned.

7 Legal Information

Copyrights & Disclaimer

Copyright ams AG, Tobelbader Strasse 30, 8141 Premstaetten, Austria-Europe. Trademarks Registered. All rights reserved. The material herein may not be reproduced, adapted, merged, translated, stored, or used without the prior written consent of the copyright owner.

Demo Kits, Evaluation Kits and Reference Designs are provided to recipient on an "as is" basis for demonstration and evaluation purposes only and are not considered to be finished end-products intended and fit for general consumer use, commercial applications and applications with special requirements such as but not limited to medical equipment or automotive applications. Demo Kits, Evaluation Kits and Reference Designs have not been tested for compliance with electromagnetic compatibility (EMC) standards and directives, unless otherwise specified. Demo Kits, Evaluation Kits and Reference Designs shall be used by qualified personnel only.

ams AG reserves the right to change functionality and price of Demo Kits, Evaluation Kits and Reference Designs at any time and without notice.

Any express or implied warranties, including, but not limited to the implied warranties of merchantability and fitness for a particular purpose are disclaimed. Any claims and demands and any direct, indirect, incidental, special, exemplary or consequential damages arising from the inadequacy of the provided Demo Kits, Evaluation Kits and Reference Designs or incurred losses of any kind (e.g. loss of use, data or profits or business interruption however caused) as a consequence of their use are excluded.

ams AG shall not be liable to recipient or any third party for any damages, including but not limited to personal injury, property damage, loss of profits, loss of use, interruption of business or indirect, special, incidental or consequential damages, of any kind, in connection with or arising out of the furnishing, performance or use of the technical data herein. No obligation or liability to recipient or any third party shall arise or flow out of ams AG rendering of technical or other services.

RoHS Compliant & ams Green Statement

RoHS Compliant: The term RoHS compliant means that ams AG products fully comply with current RoHS directives. Our semiconductor products do not contain any chemicals for all 6 substance categories, including the requirement that lead not exceed 0.1% by weight in homogeneous materials. Where designed to be soldered at high temperatures, RoHS compliant products are suitable for use in specified lead-free processes.

ams Green (RoHS compliant and no Sb/Br): ams Green defines that in addition to RoHS compliance, our products are free of Bromine (Br) and Antimony (Sb) based flame retardants (Br or Sb do not exceed 0.1% by weight in homogeneous material).

Important Information: The information provided in this statement represents ams AG knowledge and belief as of the date that it is provided. ams AG bases its knowledge and belief on information provided by third parties, and makes no representation or warranty as to the accuracy of such information. Efforts are underway to better integrate information from third parties. ams AG has taken and continues to take reasonable steps to provide representative and accurate information but may not have conducted destructive testing or chemical analysis on incoming materials and chemicals. ams AG and ams AG suppliers consider certain information to be proprietary, and thus CAS numbers and other limited information may not be available for release.

Headquarters

ams AG
Tobelbader Strasse 30
8141 Premstaetten
Austria, Europe
Tel: +43 (0) 3136 500 0

Please visit our website at www.ams.com

Buy our products or get free samples online at www.ams.com/Products

Technical Support is available at www.ams.com/Technical-Support

Provide feedback about this document at www.ams.com/Document-Feedback

For sales offices, distributors and representatives go to www.ams.com/Contact

For further information and requests, e-mail us at ams_sales@ams.com